

Roll-N-Ride or Glide-N-Ride With Front Extension Installation

Includes the following:

- Roll-N-Ride or Glide-N-Ride & Front Extension
- Two Polythene Structure Plugs With 2 10" hex bolts, washers, and UHMW Blocks
- One Bow Roller Assembly kit or Regular Bow Stop

Use Plug Link Kit to connect both pieces together and tighten

* 3/4" or 19mm socket for socket wrench to tighten UHMW blocks

